
Flop and use for the other side


Flop and use for the other side




Canopy



BACK SPAR

BACK SPAR

FRONT SPAR



These are the fairings between the rudder and the elevator.




This here for the wing placement.
B
B
from here for the wing placement
This piece goes right here
on the bottom of the fuselage
B B


Goes underneath the Elevator


Hatch on the bottom




A
B
C
C
D
D
E
E
F
F
G
H


FRONT NOSE COWLING