
Flop and use for the other side
Flop and use for the other side
Canopy
BACK SPAR
BACK SPAR
FRONT SPAR
These are the fairings between the rudder and the elevator.
Trim here for the wing placement.
Trim here for the wing placement.
This piece goes right here
on the bottom of the fuselage
B B
Hatch on the bottom
Goes underneath the Elevator
FRONT NOSE COWLING
A
B
C
C
D
D
E
E
F
F
G
H