
A


B


C


H


C


D


FF


D


E


G


E


F


F




12"


12"




Canopy


Flop ar



nd use for the other side


12"
12"


12"
Flop and use for the other side


12"


BACK SPAR
12"
BACK SPAR
FRONT SPAR


12"



12"




A
B
FOLD
12"
B
B
B
C
C
This piece g
on the botto

Trim here for the wing placement.

12"



D D

E E

F F

Trim here for the wing placement.

B B

oes right here
om of the fuselage





These are the fairings between the rudder and the elevator.


12"


12"


12"
12"


12"
12"


12"
Goes underneath the Elevator




12"


FRONT NOSE COWLING
12"


Hatch on the bottom